



PROGRAMMABLE CONTROLLERS
MELSEC-F

FX3S-30M□/E□-2AD

HARDWARE MANUAL



Manual Number	JY997D51701
Revision	D
Date	April 2015

This manual describes the part names, dimensions, mounting, cabling and specifications of the product. Before use, read this manual and the manuals of all relevant products fully to acquire proficiency in handling and operating the product. Make sure to learn all the product information, safety information, and precautions.

Store this manual in a safe place so that it can be taken out and read whenever necessary. Always forward it to the end user.

Registration: Phillips is a registered trademark of Phillips Screw Company. The company and product names described in this manual are registered trademarks or the trademarks of their respective companies.

Effective April 2015
Specifications are subject to change without notice.

© 2013 MITSUBISHI ELECTRIC CORPORATION

Safety Precaution (Read these precautions before use.)

This manual classifies the safety precautions into two categories:

WARNING and CAUTION.

	Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.
	Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight personal injury or physical damage.

Depending on the circumstances, procedures indicated by CAUTION may also cause severe injury.

It is important to follow all precautions for personal safety.

STARTUP AND MAINTENANCE PRECAUTIONS	WARNING
<ul style="list-style-type: none"> Do not touch any terminal while the PLC's power is on. Doing so may cause electric shock or malfunctions. Before cleaning or retightening terminals, cut off all phases of the power supply externally. Failure to do so may cause electric shock. Before modifying or disrupting the program in operation or running the PLC, carefully read through this manual and the associated manuals and ensure the safety of the operation. An operation error may damage the machinery or cause accidents. 	

STARTUP AND MAINTENANCE PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> Turn off the power to the PLC before attaching or detaching the memory cassette. If the memory cassette is attached or detached while the PLC's power is on, the data in the memory may be destroyed, or the memory cassette may be damaged. Do not disassemble or modify the PLC. Doing so may cause fire, equipment failures, or malfunctions. For repair, contact your local Mitsubishi Electric representative. Turn off the power to the PLC before connecting or disconnecting any connection cable. Failure to do so may cause equipment failures or malfunctions. Turn off the power to the PLC before attaching or detaching the following devices. <ul style="list-style-type: none"> Peripheral devices, display module, expansion boards, special adapters and memory cassette Failure to do so may cause equipment failures or malfunctions. 	

DISPOSAL PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> Please contact a certified electronic waste disposal company for the environmentally safe recycling and disposal of your device. 	

TRANSPORTATION AND STORAGE PRECAUTIONS	CAUTION
<ul style="list-style-type: none"> The PLC is a precision instrument. During transportation, avoid impacts larger than those specified in section 3.1 by using dedicated packaging boxes and shock-absorbing pallets. Failure to do so may cause failures in the PLC. After transportation, verify operation of the PLC and check for damage of the mounting part, etc. 	

Associated manuals

How to obtain manuals
For the necessary product manuals or documents, consult with your local Mitsubishi Electric representative.

Associated manuals
FX3S-30M□/E□-2AD comes with this document (hardware manual). For a detailed explanation of the FX3S Series hardware and information on instructions for PLC programming, refer to the relevant documents. Specifications not described in this manual are same as FX3S PLC. For details, refer to the following manual.

→ Refer to FX3S Series User's Manual - Hardware Edition.

Manual name	Manual No.	Description
FX3S Series User's Manual - Hardware Edition	JY997D48601 MODEL CODE: 09R535	Explains FX3S Series PLC specification details for I/O, wiring, installation, and maintenance.
FX3S/FX3G/FX3GC/FX3U/FX3UC Series Programming Manual - Basic & Applied Instruction Edition	JY997D16601 MODEL CODE: 09R517	Describes PLC programming for basic/applied instructions STU/SFC programming and devices.
MELSEC-Q/L/F Structured Programming Manual (Fundamentals)	SH-080782 MODEL CODE: 13JW06	Programming methods, specifications, functions, etc. required to create structured programs.
FXCPU Structured Programming Manual [Device & Common]	JY997D26001 MODEL CODE: 09R925	Devices, parameters, etc. provided in structured projects of GX Works2.
FXCPU Structured Programming Manual [Basic & Applied Instruction]	JY997D34701 MODEL CODE: 09R926	Sequence instructions provided in structured projects of GX Works2.
FXCPU Structured Programming Manual [Application Functions]	JY997D34801 MODEL CODE: 09R927	Application functions provided in structured projects of GX Works2.
FX Series User's Manual - Data Communication Edition	JY997D16901 MODEL CODE: 09R715	Explains N:N link, parallel link, computer link, no protocol communication by RS instructions/FX2N-232IF.

Manual name	Manual No.	Description
FX3S/FX3G/FX3GC/FX3U/FX3UC Series User's Manual - Analog Control Edition	JY997D16701 MODEL CODE: 09R619	Describes specifications for analog control and programming methods for FX3S/FX3G/FX3GC/FX3U/FX3UC Series PLC.
FX3S/FX3G/FX3GC/FX3U/FX3UC Series User's Manual - Positioning Control Edition	JY997D16801 MODEL CODE: 09R620	Explains the specifications for positioning control of FX3S/FX3G/FX3GC/FX3U/FX3UC Series and programming procedures.

Certification of UL, cUL standards

Please consult with Mitsubishi Electric for information on UL, cUL standard practices and the corresponding types of equipment.

Compliance with EC directive (CE Marking)

This document does not guarantee that a mechanical system including this product will comply with the following standards. Compliance to EMC directive and LVD directive of the entire mechanical system should be checked by the user/manufacturer. For more details please contact the local Mitsubishi Electric sales site.

Requirement for Compliance with EMC directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Electromagnetic Compatibility (2004/108/EC) when used as directed by the appropriate documentation.

Attention

- This product is designed for use in industrial applications.

Note

- Authorized Representative in the European Community: Mitsubishi Electric Europe B.V. Gothaer Str. 8, 40880 Ratingen, Germany

Type: Programmable Controller (Open Type Equipment)

Models: MELSEC FX3S series, FX3G series, FX3U series manufactured from June 1st, 2005

from April 1st, 2007	FX3U-232ADP	FX3U-485ADP
from December 1st, 2007	FX3U-4AD-ADP	FX3U-4DA-ADP
from November 1st, 2008	FX3U-4AD-PT-ADP	FX3U-4AD-TC-ADP
	FX3U-232ADP-MB	FX3U-485ADP-MB
	FX3U-4AD-PTW-ADP	FX3U-4AD-PNK-ADP
	FX3G-232-BD	FX3G-422-BD
	FX3G-485-BD	FX3G-EEPROM-32L
	FX3G-2AD-BD	FX3G-1DA-BD
	FX3G-8AV-BD	
from June 1st, 2009	FX3U-3A-ADP	
from February 1st, 2012	FX3U-ENET-ADP	
from March 1st, 2013	FX3S-CNV-ADP	
from September 1st, 2013	FX3S-30MR/ES-2AD	FX3S-30MT/ESS-2AD
	FX3G-4EX-BD	FX3G-2EYT-BD
	FX3G-485-BD-RJ	
from September 1st, 2014	FX3S-5DM	

Standard	Remark
EN61131-2: 2007 Programmable controllers - Equipment requirements and tests	Compliance with all relevant aspects of the standard. EMI <ul style="list-style-type: none"> Radiated Emission Conducted Emission EMS <ul style="list-style-type: none"> Radiated electromagnetic field Fast transient burst Electrostatic discharge High-energy surge Voltage drops and interruptions Conducted RF Power frequency magnetic field

Elincom Group

European Union: www.elinco.eu

Russia: www.elinc.ru

Requirement for Compliance with LVD directive

The following products have shown compliance through direct testing (of the identified standards below) and design analysis (through the creation of a technical construction file) to the European Directive for Low Voltage (2006/95/EC) when used as directed by the appropriate documentation.

Type: Programmable Controller (Open Type Equipment)

Models: MELSEC FX3S series manufactured from September 1st, 2013
FX3S-30MR/ES-2AD
FX3S-30MT/ES-2AD

Standard	Remark
EN61131-2: 2007 Programmable controllers - Equipment requirements and tests	The equipment has been assessed as a component for fitting in a suitable enclosure which meets the requirements of EN61131-2: 2007

Caution for compliance with EC Directive

Installation in Enclosure

Programmable logic controllers are open-type devices that must be installed and used within conductive control boxes. Please use the FX3S Series programmable logic controllers while installed in conductive shielded control boxes. Please secure the control box lid to the control box (for conduction). Installation within a control box greatly affects the safety of the system and aids in shielding noise from the programmable logic controller.

Analog input/output

The analog input/output have been found to be compliant to the European standards in the aforesaid manual and directive. However, for the very best performance from what are in fact delicate measuring and controlled output devices, Mitsubishi Electric would like to make the following points.

As analog devices are sensitive by nature, their use should be considered carefully. For users of proprietary cables (integral with sensors or actuators), these users should follow those manufacturers' installation requirements.

Mitsubishi Electric recommends that shielded cables be used. If NO other EMC protection is provided, users may experience temporary loss or accuracy between +10 %/-10 % in very heavy industrial areas.

However, Mitsubishi Electric suggests that adequate EMC precautions be followed for the users complete control system.

- Sensitive analog cables should not be laid in the same trunking or cable conduit as high voltage cabling. Where possible, users should run analog cables separately.
- Good cable shielding should be used. When terminating the shield at Earth, ensure that no earth loops are accidentally created.
- When reading analog values, EMC accuracy can be improved by averaging the readings. This can be achieved either through functions on the analog products or through a user's program in the FX3S Series PLC main unit.

Incorporated Items

Check if the following product and items are included in the package:

	Included Items	
FX3S-30MR/ES-2AD, FX3S-30MT/ES-2AD, FX3S-30MT/ESS-2AD	Product	1 unit
	Dust proof protection sheet	1 sheet
	Manuals [Japanese/English]	1 manual


1. Feature

FX3S-30M□/E□-2AD is a product based on FX3S PLC, with built-in analog input in place of variable analog potentiometers.

(Refer to the following figure)
Specifications other than the built-in analog input are the same as FX3S PLC. For details, refer to FX3S Series User's Manual - Hardware Edition. For details on the built-in analog input, refer to Chapter 6.


Variable analog potentiometer

Analog input terminal block




2. Outline

2.1 Part names




No.	Name	
[1]	Top cover	
[2]	Terminal names	
[3]	Terminal block covers	
[4]	Input display LEDs (red)	
[5]	Peripheral device connecting connector cover	
[6]	Operation status display LEDs	
	POW	Green On while power is on the PLC.
	RUN	Green On while the PLC is running.
[6]	ERR	Red Flashing when a program error occurs.
		Red Lights when a CPU error occurs.
[7]	Output display LEDs (red)	
[8]	The year and month of production	
[9]	Model name (abbreviation)	
[10]	DIN rail mounting hooks	

When the top covers are open




No.	Name
[1]	Optional equipment connector
[2]	Power supply terminal, Input (X) terminals
[3]	Analog input terminal block
[4]	RUN/STOP switch
[5]	Peripheral device connecting connector (USB)
[6]	Peripheral device connecting connector (RS-422)
[7]	Service power supply terminal, Output (Y) terminals
[8]	Terminal cover
[9]	Optional equipment connecting screw holes

Right side



The authentication label for authorized products is affixed to the right side of the product to avoid to be forged. Products that do not have the genuine product certification label or nameplate are not covered by the warranty.

2.2 External dimensions and weight



Model name	W: mm (inches)	W1: mm (inches) Direct mounting hole pitches	MASS (Weight): kg (lbs)
FX3S-30M□/E□-2AD	100 (3.94")	92 (3.63")	Approx. 0.45 (0.99 lbs)

Installation

- 35-mm-wide DIN rail or Direct (screw) mounting (M4×2)

3. Installation (generic specifications)

As for installation of the special adapters and expansion boards, refer to the following manual.
→ Refer to FX3s Series User's Manual - Hardware Edition.

INSTALLATION PRECAUTIONS **CAUTION**

- Use the product within the generic environment specifications described in section 3.1 of this manual. Never use the product in areas with excessive dust, oily smoke, conductive dusts, corrosive gas (salt air, Cl₂, H₂S, SO₂ or NO₂), flammable gas, vibration or impacts, or expose it to high temperature, condensation, or rain and wind. If the product is used in such conditions, electric shock, fire, malfunctions, deterioration or damage may occur.
- Do not touch the conductive parts of the product directly. Doing so may cause device failure or malfunctions.
- Install the product securely using a DIN rail or mounting screws.
- Install the product on a flat surface. If the mounting surface is rough, undue force will be applied to the PC board, thereby causing nonconformities.
- When drilling screw holes or wiring, make sure cutting or wire debris do not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Be sure to remove the dust proof sheet from the PLC's ventilation port when installation work is completed. Failure to do so may cause fire, equipment failures or malfunctions.
- Connect the peripheral device cables securely to their designated connectors. Loose connections may cause malfunctions.
- Turn off the power to the PLC before attaching or detaching the following devices. Failure to do so may cause device failures or malfunctions.
 - Peripheral devices, display module, expansion boards, special adapters and memory cassette

Notes

- When a dust proof sheet is supplied with units, keep the sheet applied to the ventilation slits during installation and wiring work.
- To prevent temperature rise, do not install the PLC on a floor, a ceiling or a vertical surface. Install it horizontally on a wall as shown in section 3.2.
- Keep a space of 50 mm (1.97") or more between the unit main body and another device or structure (part A). Install the unit as far away as possible from high-voltage lines, high-voltage devices and power equipment.

3.1 Generic specifications

Item	Specification			
Ambient temperature	0 to 55 °C (32 to 131 °F) when operating and -25 to 75 °C (-13 to 167 °F) when stored			
Ambient humidity	5 to 95 %RH (no condensation) when operating			
Vibration resistance ^{*1}	When installed on DIN rail	Frequency (Hz)	Acceleration (m/s ²)	Half amplitude (mm)
		10 to 57	-	0.035
	When installed directly	10 to 57	-	0.075
		57 to 150	4.9	-
Shock resistance ^{*1}	147 m/s ² Acceleration, Action time: 11 ms, 3 times by half-sine pulse in each direction X, Y, and Z			
Noise resistance	By noise simulator at noise voltage of 1,000 Vp-p, noise width of 1 μs, rise time of 1 ns and period of 30 to 100 Hz			
Dielectric withstand voltage ^{*2}	1.5 kV AC for 1 min	Between each terminals and ground terminal ^{*2}		
	500 V AC for 1 min			
Insulation resistance ^{*2}	5 MΩ or more by 500 V DC megger			
Grounding	Class D grounding (grounding resistance: 100 Ω or less) <Common grounding with a heavy electrical system is not allowed.> ^{*3}			
Working atmosphere	Free from corrosive or flammable gas and excessive conductive dusts			
Working altitude	<2000 m ^{*4}			

*1 The criterion is shown in IEC61131-2.

*2 Dielectric withstand voltage and insulation resistance are shown in the following table.

Terminal	Dielectric strength	Insulation resistance
■ Terminals of main units		
Between power supply terminal (AC power) and ground terminal	1.5 kV AC for 1 min	5 MΩ or more by 500 V DC megger
Between input terminal (24 V DC) and ground terminal	500 V AC for 1 min	
Between output terminal (relay) and ground terminal	1.5 kV AC for 1 min	
Between output terminal (transistor) and ground terminal	500 V AC for 1 min	
Main unit analog input terminal and ground terminal	Not allowed	Not allowed
■ Terminals of expansion boards, special adapters		
Between terminal of expansion board (except FX3G-4EX-BD and FX3G-2EYT-BD) and ground terminal	Not allowed	Not allowed
Between FX3G-4EX-BD input terminal (24 V DC) and ground terminal	500 V AC for 1 min	5 MΩ or more by 500 V DC megger
Between FX3G-2EYT-BD output terminal (transistor) and ground terminal		
Between terminal of special adapter and ground terminal		

For dielectric with stand voltage test and insulation resistance test of each product, refer to the following manual.
→ Refer to FX3s Series User's Manual - Hardware Edition.


*3 For common grounding, refer to section 4.3.

*4 The PLC cannot be used at a pressure higher than the atmospheric pressure to avoid damage.

3.2 Installation location


Install the PLC in an environment conforming to the generic specifications (section 3.1), installation precautions and notes.

Installation location in enclosure



Space in enclosure

Special adapter can be connected on the left sides of the main unit. If you intend to add special adapter in the future, keep necessary spaces on the left sides.



3.2.1 Affixing the dust proof sheet

The dust proof sheet should be affixed to the ventilation port before beginning the installation and wiring work. Be sure to remove the dust proof sheet when the installation and wiring work is completed.

→ For the affixing procedure, refer to the instructions on the dust proof sheet.

3.3 Procedures for installing to DIN rail

The products can be installed on a DIN46277 rail [35 mm (1.38") wide].


This section explains the installations of the main units.

For the special adapters, refer to the following manual.


→ Refer to FX3s Series User's Manual - Hardware Edition.

3.3.1 Installation


- 1) Push out all DIN rail mounting hooks (below fig. A).



- 2) Fit the upper edge of the DIN rail mounting groove (right fig. B) onto the DIN rail.



- 3) Lock the DIN rail mounting hooks (below fig. C) while pressing the PLC against the DIN rail.



3.4 Procedures for installing directly (with M4 screws)

The product can be installed directly on the panel (with screws). This section explains the installation of the main units. For the special adapters, refer to the following manual.


→ Refer to FX3s Series User's Manual - Hardware Edition.

3.4.1 Mounting hole pitches

Refer to the External Dimensions (section 2.2) for the product's mounting hole pitch information.

3.4.2 Installation

- 1) Make mounting holes in the mounting surface referring to the external dimensions diagram.
- 2) Fit the main unit (A in the right figure) based on the holes, and secure it with M4 screws (B in the right figure).



4. Power supply/input/output specifications and examples of external wiring

For the details refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

DESIGN PRECAUTIONS **WARNING**

- Make sure to have the following safety circuits outside of the PLC to ensure safe system operation even during external power supply problems or PLC failure. Otherwise, malfunctions may cause serious accidents.
 - 1) Most importantly, have the following: an emergency stop circuit, a protection circuit, an interlock circuit for opposite movements (such as normal vs. reverse rotation), and an interlock circuit (to prevent damage to the equipment at the upper and lower positioning limits).
 - 2) Note that when the PLC CPU detects an error, such as a watchdog timer error, during self-diagnosis, all outputs are turned off. Also, when an error that cannot be detected by the PLC CPU occurs in an input/output control block, output control may be disabled. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
 - 3) If an overload of the 24 V DC service power supply occurs, the voltage automatically drops, inputs in the PLC are disabled, and all outputs are turned off. External circuits and mechanisms should be designed to ensure safe machinery operation in such a case.
 - 4) Note that when an error occurs in a relay or transistor output device, the output could be held either on or off. For output signals that may lead to serious accidents, external circuits and mechanisms should be designed to ensure safe machinery operation in such a case.

DESIGN PRECAUTIONS **CAUTION**

- Do not bundle the control line together with or lay it close to the main circuit or power line. As a guideline, lay the control line at least 100 mm (3.94") or more away from the main circuit or power line. Noise may cause malfunctions.
- Install module so that excessive force will not be applied to peripheral device connectors. Failure to do so may result in wire damage/breakage or PLC failure.

Notes

- Even if the AC power supply causes an instantaneous power failure for less than 10 ms, the PLC can continue to operate.
- If a long-time power failure or an abnormal voltage drop occurs, the PLC stops, and output is turned off. When the power supply is restored, it will automatically restart (when the RUN input is on).

WIRING PRECAUTIONS **WARNING**

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

WIRING PRECAUTIONS **CAUTION**

- Connect the AC power supply wiring to the dedicated terminals described in this manual. If an AC power supply is connected to a DC input/output terminal or DC power supply terminal, the PLC will burn out.
- Noise resistance may be lower when the L and N wires of an AC power supply are not wired correctly. Please wire using the correct polarity.
- Do not wire vacant terminals externally. Doing so may damage the product.
- Perform class D grounding (grounding resistance: 100 Ω or less) to the grounding terminal on the main unit with a wire 2 mm² or thicker. Do not use common grounding with heavy electrical systems (refer to section 4.3).
- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.
- Make sure to properly wire to the main unit in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
 - Make sure to properly wire to the main unit in accordance with the rated voltage, current, and frequency of each terminal.
 - The disposal size of the cable end should follow the dimensions described in the manual.
 - Tightening torque should follow the specifications in the manual.
 - Tighten the screws using a Phillips-head screwdriver No.2 (shaft diameter 6mm (0.24") or less). Make sure that the screwdriver does not touch the partition part of the terminal block.

Notes

- Input/output wiring 50 to 100 m (164'1" to 328'1") long will cause almost no problems of noise, but, generally, the wiring length should be less than 20 m (65'7") to ensure the safety.


4.1 Wiring

4.1.1 Cable end treatment and tightening torque

For the terminals of FX3s series PLC, M3 screws are used. The electric wire ends should be treated as shown below. Tighten the screws to a torque of 0.5 to 0.8 N•m.

Do not tighten terminal screws with a torque outside the above-mentioned range. Failure to do so may cause equipment failures or malfunctions.


- When one wire is connected to one terminal



<Reference>

Terminal Manufacturer	Type No.	Certification	Pressure Bonding Tool
J.S.T. Mfg. Co., Ltd.	FV1.25-B3A FV2-MS3	UL Listed	YA-1 (JST)

- When two wires are connected to one terminal



<Reference>

Terminal Manufacturer	Type No.	Certification	Pressure Bonding Tool
J.S.T. Mfg. Co., Ltd.	FV1.25-B3A	UL Listed	YA-1 (JST)

4.2 Power supply specifications and example of external wiring

For details, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.


4.2.1 Power supply specifications

Item	Specification
Supply voltage	100 to 240 V AC
Allowable supply voltage range	85 to 264 V AC
Rated frequency	50/60 Hz
Allowable instantaneous power failure time	Operation can be continued upon occurrence of instantaneous power failure for 10 ms or less.
Power fuse	250 V 1 A
Rush current	15 A max. 5 ms or less/100 V AC 28 A max. 5 ms or less/200 V AC
Power consumption*1	21 W
24 V DC service power supply	400 mA

*1 This item shows values when all 24 V DC service power supplies are used in the maximum configuration connectable to the main unit, and includes the input current (5 or 7 mA per point).

4.2.2 Example of external wiring


100 to 240 V AC power is supplied to the main unit.



4.3 Grounding

Ground the PLC as stated below.

- Perform class D grounding. (Grounding resistance: 100 Ω or less)
- Ground the PLC independently if possible. If it cannot be grounded independently, ground it jointly as shown below.



- Use ground wires thicker than AWG14 (2 mm²).
- Position the grounding point as close to the PLC as possible to decrease the length of the ground wire.

4.4 Input specifications and external wiring


For details, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

4.4.1 Input specifications

Item	Specification	
Number of input points	16 points	
Input connecting type	Fixed terminal block (M3 screw)	
Input form	Sink/Source	
Input signal voltage	24 V DC +10%, -10%	
Input impedance	X000 to X007	3.3 kΩ
	X010 to X017	4.3 kΩ
Input signal current	X000 to X007	7 mA/24 V DC
	X010 to X017	5 mA/24 V DC
ON input sensitivity current	X000 to X007	4.5 mA or more
	X010 to X017	3.5 mA or more
OFF input sensitivity current	1.5 mA or less	
Input response time	Approx. 10 ms	
Input signal form	Sink input	No-voltage contact input NPN open collector transistor
	Source input	No-voltage contact input PNP open collector transistor
Input circuit insulation	Photocoupler insulation	
Input operation display	LED on panel lights when photocoupler is driven.	

4.4.2 Examples of input wiring



4.4.3 Instructions for connecting input devices

As for the details of Instructions for connecting input devices, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

4.5 Relay output specifications and example of external wiring

For details, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

4.5.1 Relay output specifications

Item	Specification	
Number of output points	14 points	
Output connecting type	Fixed terminal block (M3 screw)	
Output form	Relay	
External power supply	30 V DC or less 240 V AC or less*1	
Max. load	Resistance load	2 A/point ²
	Inductive load	80 VA ³
Min. load	5 V DC, 2 mA (reference value)	

Item	Specification
Open circuit leakage current	-
Response time	OFF→ON ON→OFF
Output circuit insulation	Mechanical insulation
Output operation display	LED on panel lights when power is applied to relay coil.

*1 250 V AC or less when the unit does not comply with CE, UL or cUL standards.

*2 The total load current of resistance loads per common terminal should be the following value.

- 1 output point/common terminal: 2 A or less
- 4 output points/common terminal: 8 A or less

As for the number of outputs per common terminal, refer to "Chapter 5 interpretation of partition" and the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.


*3 UL and cUL standards approved at 120 and 240 V AC.

4.5.2 Life of relay output contact

As for the details of life of relay output contact, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

4.5.3 Example of relay output wiring



4.5.4 Cautions in external wiring

As for the details of cautions in external wiring, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

4.6 Transistor output specifications and example of external wiring

For details, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

4.6.1 Transistor output specifications

Item	Specification
Number of output points	14 points
Output connecting type	Fixed terminal block (M3 screw)
Output form	FX3s-30MT/ES-2AD Transistor (Sink) FX3s-30MT/ESS-2AD Transistor (Source)
External power supply	5 to 30 V DC
Max. load	Resistance load 0.5 A/point ^{*1} Inductive load 12 W/24 V DC ^{*2}
Open circuit leakage current	0.1 mA or less/30 V DC
ON voltage	1.5 V or less
Response time	OFF→ON Y000, Y001 5 μs or less/10 mA or more (5 to 24 V DC) ON→OFF Y002 to Y015 0.2 ms or less/200 mA or more (at 24 V DC)
Output circuit insulation	Photocoupler insulation
Output operation display	LED on panel lights when photocoupler is driven.

*1 The total load current of resistance loads per common terminal should be the following value.

- 1 output point/common terminal: 0.5 A or less
- 4 output points/common terminal: 0.8 A or less

As for the number of outputs per common terminal, refer to "Chapter 5 interpretation of partition" and the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

*2 The total of inductive loads per common terminal should be the following value.


- 1 output point/common terminal: 12 W or less/24 V DC
- 4 output points/common terminal: 19.2 W or less/24 V DC

As for the number of outputs per common terminal, refer to "Chapter 5 interpretation of partition" and the following manual.


→ Refer to FX3s Series User's Manual - Hardware Edition.

4.6.2 External wiring of transistor output

1. External wiring of sink output type



2. External wiring of source output type



4.6.3 Cautions in external wiring

As for the details of cautions in external wiring, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

5. Terminal block layouts


For details on the terminal block layout, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

Interpretation of partition

The partition of the output terminals (see following figure) indicates the range of the output connected to the same common.

Example: FX3s-30MT/ES-2AD



6. Built-in analog specifications and wiring

For details on the built-in analog input specifications and wiring, refer to the following manual.

→ Refer to FX3s Series User's Manual - Hardware Edition.

WARNING

- Make sure to cut off all phases of the power supply externally before attempting installation or wiring work. Failure to do so may cause electric shock or damage to the product.

CAUTION

- When drilling screw holes or wiring, make sure cutting or wire debris does not enter the ventilation slits. Failure to do so may cause fire, equipment failures or malfunctions.

CAUTION

WIRING PRECAUTIONS

- Make sure to observe the following precautions in order to prevent any damage to the machinery or accidents due to abnormal data written to the PLC under the influence of noise:
 - 1) Do not bundle the power line or shield of the analog input/output cable together with or lay it close to the main circuit, high-voltage line, or load line. Otherwise, noise disturbance and/or surge induction are likely to take place. As a guideline, lay the control line at least 100 mm (3.94") or more away from the main circuit, high-voltage line, or load line.
 - 2) Ground the shield of the analog input/output cable at one point on the signal receiving side. However, do not use common grounding with heavy electrical systems.
- Make sure to properly wire to the terminal block (European type) in accordance with the following precautions. Failure to do so may cause electric shock, equipment failures, a short-circuit, wire breakage, malfunctions, or damage to the product.
 - The disposal size of the cable end should follow the dimensions described in the manual.
 - Tightening torque should follow the specifications in the manual.
 - Twist the end of strand wire and make sure that there are no loose wires.
 - Do not solder-plate the electric wire ends.
 - Do not connect more than the specified number of wires or electric wires of unspecified size.
 - Affix the electric wires so that neither the terminal block nor the connected parts are directly stressed.

6.1 Analog input terminal block (European type)

1) Wire size
Wiring to analog device should use wire from following table.

No. of wire per terminal	Wire size		
	Solid wire	Stranded wire	Ferrules with plastic sleeve
1	0.14 to 1.5 mm ² (AWG26 to 16)	0.14 to 1.0 mm ² (AWG26 to 16)	0.25 to 0.5 mm ² (AWG24 to 20)
2	0.14 to 0.5 mm ² (AWG26 to 20)	0.14 to 0.2 mm ² (AWG26 to 24)	-


2) Termination
Strip the coating of strand wire and twist the cable core before connecting it, or strip the coating of single wire before connecting it. An alternative connection is to use a ferrule with insulating sleeve.

Manufacturer	Model	Caulking tool
Phoenix Contact Co., Ltd.	AI 0.25-6BU (AWG24) AI 0.34-6TQ (AWG22) AI 0.5-6WH (AWG20)	CRIMPFOX 6 ^{*1} (or CRIMPFOX 6T-F ^{*2})

*1 Old model name: CRIMPFOX ZA 3

*2 Old model name: CRIMPFOX UD 6

- Stranded wire/solid wire
- Stick terminal with insulating sleeve



When using a stick terminal with an insulating sleeve, choose a wire with proper cable sheath referring to the above outside dimensions, otherwise the wire cannot be inserted easily.

Tighten the screws to a torque of 0.22 to 0.25 N·m. Do not tighten terminal screws with a torque outside the above-mentioned range. Failure to do so may cause equipment failures or malfunctions.

3) Tool
For tightening the terminal, use a commercially available small screwdriver having a straight form that is not widened toward the end as shown right.

Caution:
If the diameter of screwdriver grip is too small, tightening torque will not be able to be achieved. To achieve the appropriate tightening torque shown in the table above, use the following screwdriver or appropriate replacement (grip diameter : approximately 25 mm (0.98")).


Manufacturer	Model name
Phoenix Contact Co., Ltd.	SZS 0.4×2.5

6.2 Analog input specifications and external wiring

6.2.1 Analog input performance specifications

Item	Input specification
Analog input range	0 to 10 V DC (Input resistance: 115.7 kΩ)
Absolute maximum input	-0.5 V, +15 V
Digital output	10 bits, binary
Device allocation	D8270 (The digital value of CH1 is stored) D8271 (The digital value of CH2 is stored)
Resolution	10 mV (10 V/1000)
Total accuracy	- ± 1.0 % (± 100 mV) for 10 V full scale (when ambient temperature is 25 ± 5 °C) - ± 2.0 % (± 200 mV) for 10 V full scale (when ambient temperature is 0 to 55 °C)
A/D conversion time	180 μs (The data will be updated at every scan time of the PLC.)
Input characteristics	
Insulation method	No insulation between each channel or the PLC.
Occupied points	0 point (This number is not related to the maximum number of input/output points of the PLC.)

6.2.2 Example of analog input



V□+, ch□: □ represents the channel number.

*1 Use the 2-core shielded twisted pair cable for the analog input lines, and separate the analog input lines from other power lines or inductive lines.

*2 Make sure to short-circuit the "V□+" and "V-" terminals when ch is not used.

6.2.3 Analog input terminal block layouts



This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi Electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

Warranty
Mitsubishi will not be held liable for damage caused by factors found not to be the cause of Mitsubishi; opportunity loss or lost profits caused by faults in the Mitsubishi products; damage, secondary damage, accident compensation caused by special factors unpredictable by Mitsubishi; damages to products other than Mitsubishi products; and to other duties.

For safe use

- This product has been manufactured as a general-purpose part for general industries, and has not been designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- Before using the product for special purposes such as nuclear power, electric power, aerospace, medicine or passenger movement vehicles, consult with Mitsubishi Electric.
- This product has been manufactured under strict quality control. However when installing the product where major accidents or losses could occur if the product fails, install appropriate backup or failsafe functions in the system.