

Type	Function	Comments
FX2NC-RTC	Clock function only	FX2NC series battery back-up for RTC.
FX2NC-EEPROM-4C	Clock + 4k steps EEPROM	
FX2NC-EEPROM16C	Clock + 16k steps EEPROM	

- When replacing/installing memory board, turn off the main unit power source.
When replacing/installing memory board, care must be taken not to touch the exposed EEPROM chip.
For replacement and installation of memory board refer to the procedure in the PLC main unit manual.
- EEPROMs are not initialized. When used for the first time, the CPU error LED may flicker.
Transfer or write a program directly or write all NOP in on-line program mode using the FX-20P or FX-30P.

- For transportation always use an isolation bag.

<<Clock board>> FX2NC-RTC


- The calendar function for day, month, year, hour, minute and second is provided with leap year correction.
- The FX2NC-RTC uses the main unit program memory.
- For details see the PLC main unit manual.

<<EEPROM board>> FX2NC-EEPROM-4C, 16C (with clock function)

- After program transfer or write, be sure to verify and check for proper operation. If an error is found, transfer and verify again.
- When writing a program, turn OFF the memory protect switch. Please keep it in the ON position during program operation.

Industrial automation
Elincom Group

European Union: v

Russia: www.elinc

 原产地 日本国
合格证

Made in Japan

MITSUBISHI ELECTRIC

 April 2015
JY992D76101C

Attention

- This product is designed for use in industrial applications.

Note

- Manufactured by: Mitsubishi Electric Corporation
2-7-3 Marunouchi, Chiyoda-ku, Tokyo,
100-8310 Japan
- Authorized Representative in the European Community:
Mitsubishi Electric Europe B.V.
Gothaer Str. 8, 40880 Ratingen, Germany